

# doubleback collar instructions

TO BEGIN, WRAP COLLAR AROUND DOG'S NECK, STRIPES FACING OUT.

## straightthru method *(normal strength)*



1. Slide webbing tail through buckle slot—under RUFFWEAR logo.



2. Pass webbing through second buckle slot. Pull webbing through buckle to micro-adjust collar's fit.



3. Continue webbing through V-ring slot. Secure tail with black slider.



4. Collar in StraightThru mode.

## doubleback method *(double strength)*



1. Slide webbing tail through buckle slot—under RUFFWEAR logo.



2. Pass webbing through second buckle slot.



3. Bring webbing tail back over buckle and pass through first buckle slot again—the DoubleBack.



4. Secure the tail with black slider. Solid color webbing will show in DoubleBack mode.